Why is my Lamb acting funny when I plug it in?

If your Lamb is making a funny noise or the LEDs are flashing white, it is likely that your power supply isn't providing enough power. The Lamb requires at least 200ma to function properly. Please check your power supply and make sure you're not plugged into a 100ma port. Under powering your pedal for any period of time can damage the unit and will void your warranty.

Revision #1
Created 10 February 2022 20:31:59 by Junior Thomason
Updated 10 February 2022 20:32:50 by Junior Thomason