

# Control Change Press-N-Release

Similar to CC Toggle but operates in a momentary fashion

Enter the CC#'s, Values, and Channel for which to send your message.

This feature works in a momentary fashion, when pressing (and holding) the button associated with this Midi type, the CC# and Value above Press will be sent. When releasing the button associated with this Midi type, the CC# and Value above Release will be sent.

This Midi type can be used to temporarily jump to one setting, such as 100% wet mix or max decay time, and then quickly return back to your desired setting. This can also be used to engage or bypass a button on a Strymon pedal as they require one CC# and Value to be sent on the press and another Value sent on the release.

\* When using this Midi type ***and you expect to hold the button down for longer than a half of a second.*** Both the short press and long press of the same button must be assigned to this Midi type and must also use the same values, if not, the desired result may not be as expected.

MCX Web Editor | Jet Pedals

appjetpedals.com/editor#/assign-messages

MCX Web Editor

Saved Presets Editor Start Over Disconnect

### MCX Web Editor

#### Step 3: Assign MIDI Messages

Red Bank → Short Press A

Message 1 Press-N-Release CC

CC#	CC#	Channel
1	23	1
Value	Value	
0	127	
Press	Release	

Message 2 Empty Message

Revision #4

Created 27 July 2020 01:29:43 by Junior Thomason

Updated 30 July 2020 02:00:42 by Junior Thomason