

# Control Change Press-N-Release

Similar to CC Toggle but operates in a momentary fashion

Enter the CC#'s, Values, and Channel for which to send your message.

This feature works in a momentary fashion, when pressing (and holding) the button associated with this Midi type, the CC# and Value above Press will be sent. When releasing the button associated with this Midi type, the CC# and Value above Release will be sent.

This Midi type can be used to temporarily jump to one setting, such as 100% wet mix or max decay time, and then quickly return back to your desired setting. This can also be used to engage or bypass a button on a Strymon pedal as they require one CC# and Value to be sent on the press and another Value sent on the release.

\* When using this Midi type ***and you expect to hold the button down for longer than a half of a second***. ***Both the short press and long press of the same button must be assigned to this Midi type and must also use the same values***, if not, the desired result may not be as expected.

MCX Web Editor | Jet Pedals

app.jetpedals.com/editor#/assign-messages

MCX Web Editor

Saved Presets Editor Start Over Disconnect

### Step 3: Assign MIDI Messages

Red Bank → Short Press A

Message 1 Press-N-Release CC

CC#	CC#	Channel
1	23	1

Value	Value
0	127

Press Release

Message 2 Empty Message

Updated Thu, Jul 30, 2020 2:00 AM by Junior Thomason