
# Control Change Press-N-Release

Similar to CC Toggle but operates in a momentary fashion

> Enter the CC#'s, Values, and Channel for which to send your message.
>
> This feature works in a momentary fashion, when pressing (and holding) the button associated with this Midi type, the CC# and Value above Press will be sent. When releasing the button associated with this Midi type, the CC# and Value above Release will be sent.
>
> This Midi type can be used to temporarily jump to one setting, such as 100% wet mix or max decay time, and then quickly return back to your desired setting. This can also be used to engage or bypass a button on a Strymon pedal as they require one CC# and Value to be sent on the press and another Value sent on the release.
>
> * When using this Midi type ***and you expect to hold the button down for longer than a half of a second***. *Both the short press and long press of the same button must be assigned to this Midi type and must also use the same values*, if not, the desired result may not be as expected.




---

Revision #4
Created 27 July 2020 01:29:43 by Junior Thomason
Updated 30 July 2020 02:00:42 by Junior Thomason