


Control Change

Generally used to control individual functions within your Midi device

Enter the CC#, Value, and Channel for which to send your message



The screenshot shows a web browser window with the URL `app.jetpedals.com/editor#/assign-messages`. The page title is "MCX Web Editor". The interface includes a top navigation bar with "Saved Presets", "Editor", "Start Over", and "Disconnect" buttons. The main content area is titled "MCX Web Editor" and displays "Step 3: Assign MIDI Messages". Below this, it shows "Red Bank → Short Press A". The configuration for "Message 1" is as follows:

Message 1
CC
CC#
23
Channel
1
Value
127

Below the "Message 1" section, there is a "Message 2" section with a dropdown menu currently set to "Empty Message".

Revision #3

Created Mon, Jul 27, 2020 1:14 AM by Junior Thomason

Updated Thu, Jul 30, 2020 1:47 AM by Junior Thomason