


Control Change

Generally used to control individual functions within your Midi device

Enter the CC#, Value, and Channel for which to send your message



The screenshot shows a web browser window with the URL `appjetpedals.com/editor#/assign-messages`. The page title is "MCX Web Editor". The interface includes a navigation bar with "Saved Presets", "Editor", "Start Over", and "Disconnect" buttons. The main content area is titled "MCX Web Editor" and displays "Step 3: Assign MIDI Messages". Below this, it shows "Red Bank → Short Press A" and a configuration form for "Message 1". The form includes a dropdown menu set to "CC", input fields for "CC#" (23), "Channel" (1), and "Value" (127). "Message 2" is currently set to "Empty Message".

Revision #3

Created 27 July 2020 01:14:06 by Junior Thomason

Updated 30 July 2020 01:47:16 by Junior Thomason