

Program Change Toggle

Used to toggle between two separate PC numbers

Enter the PC#'s and Channel for which to send your message.

When pressing the button associated with this Midi type, the PC# above Max/On will be sent first then the PC# above Min/Off will be sent on the second press, this process will repeat each time the button is pressed. Switching banks will reset the counter and the PC# above Max/On will be sent with the first button press.

The screenshot shows a web browser window with the address bar displaying 'app.jetpedals.com/editor/assign-messages'. The page title is 'MCX Web Editor'. The interface includes a top navigation bar with 'Saved Presets', 'Editor', 'Start Over', and a 'Disconnect' button. The main content area is titled 'MCX Web Editor' and displays a configuration window for 'Step 3: Assign MIDI Messages'. This window is for the 'Red Bank → Short Press A' and shows three message slots. Message 1 is set to 'PC Toggle' and has two PC# fields: '1' for 'Min / Off' and '23' for 'Max / On', along with a 'Channel' field set to '1'. Messages 2 and 3 are currently set to 'Empty Message'.

Message	Message Name	PC#	PC#	Channel
Message 1	PC Toggle	1 Min / Off	23 Max / On	1
Message 2	Empty Message			
Message 3	Empty Message			

Revision #2

Created 27 July 2020 01:22:32 by Junior Thomason

Updated 30 July 2020 01:54:51 by Junior Thomason