


# Program Change Toggle

Used to toggle between two separate PC numbers

Enter the PC#'s and Channel for which to send your message.

When pressing the button associated with this Midi type, the PC# above Max/On will be sent fist then the PC# above Min/Off will be sent on the second press, this process will repeat each time the button is pressed. Switching banks will reset the counter and the PC# above Max/On will be sent with the first button press.



MCX Web Editor | Jet Pedals

app.jetpedals.com/editor#/assign-messages

MCX Web Editor

Saved Presets Editor Start Over Disconnect

### MCX Web Editor

#### Step 3: Assign MIDI Messages

Red Bank → Short Press A

Message 1 PC Toggle

PC#	PC#	Channel
1	23	1
Min / Off	Max / On	

Message 2 Empty Message

Message 3 Empty Message

Revision #2

Created Mon, Jul 27, 2020 1:22 AM by Junior Thomason

Updated Thu, Jul 30, 2020 1:54 AM by Junior Thomason