


Stop MIDI Clock

Used to stop sending Midi clock information

There is no data to be entered for this Midi type, once assigned to a button it will now stop the Midi clock when pressed.



Revision #2

Created Mon, Jul 27, 2020 2:02 AM by Junior Thomason

Updated Thu, Jul 30, 2020 2:17 AM by Junior Thomason