


Stop MIDI Clock

Used to stop sending Midi clock information

There is no data to be entered for this Midi type, once assigned to a button it will now stop the Midi clock when pressed.



Revision #2

Created 27 July 2020 02:02:00 by Junior Thomason

Updated 30 July 2020 02:17:20 by Junior Thomason