Blue Bank (Tap/Tuner Mode)

The blue bank is used to access tap tempo and the tuner. When in the blue bank, the follow buttons have been pre-programmed and cannot be user assignable.

- Short Press Button A - toggles the tuner on/off
- Short Press Button B - exits the Tap/Tuner Mode
- Short Press Button C - tap tempo

Revision #2
Created 6 November 2020 15:58:56 by Junior Thomason
Updated 6 November 2020 20:13:38 by Junior Thomason