

Connecting to the Inputs of the JET Stream

The input connectors are XLR & ¼" combo jacks which can accept balanced and unbalanced input signals.

When your speaker cabinet is further away than 15' from your modeler, we recommend using either ¼" TRS or XLR balanced cables. This will reduce any stray noise that may be picked up on the input cables. Make sure your modeler is capable of sending a balanced signal to eliminate any stray noise.

If your speaker cabinet is within 15' of your modeler, standard ¼" mono (TS) cables can be used to connect to the JET Stream. Running mono/unbalanced cables longer than 15' run the risk of losing signal integrity and possible high end frequency roll off may occur.

* The use of standard ¼" unbalanced cables will have a -6 dB signal loss at the input preamp of the JET Stream compared to using balanced XLR or TRS cables.

Revision #1

Created 14 November 2025 17:50:04 by Junior Thomason

Updated 14 November 2025 17:51:20 by Junior Thomason