

The Power Amp Keeps Cutting Out. What Can I Do?

The JET Stream has an internal protection circuit which keeps the amp from clipping too much and from overheating. When connecting lower impedance speaker cabinets and/or multiple speaker cabinets to the JET Stream, it will have to work harder and can go into protection mode. If you run into this scenario, either reduce the input signal going into the inputs of the JET Stream or turn down the Master Volume knob to reduce the stress on the power amp.

Revision #1

Created 14 November 2025 18:03:45 by Junior Thomason

Updated 14 November 2025 18:04:14 by Junior Thomason