

How many presets can I save on the pedal

The Lamb can save up to 100 presets. The first three presets can be saved by using the buttons and knobs on the pedal. The remaining 97 presets can be saved using a MIDI controller.

Revision #2

Created 10 February 2022 20:25:14 by Junior Thomason

Updated 10 February 2022 20:27:45 by Junior Thomason