

# How to Connect

Midi communication to the Lamb conforms to the specification for TRS to Midi adapters issued by the Midi Association. So what does this mean for me? In order to communicate via Midi you will need either a 5 pin to 1/4" TRS adapter cable that is wired to the TRS specification (link to a compatible cable found [here](#)) or if you wish to make your own patch cables, a link to the wiring diagram and the midi specification can be found [here](#). You can also use a midi box that converts 5 pin Midi to multiple TRS patch cable connections and will need to conform to the TRS specification (currently only the Midi Box 4 by Disaster Area Designs), or a compatible Midi controller with TRS midi output's like the Futurist by Matthews Effects or various controllers by Disaster Area Designs and MorningStar Engineering.

---

Revision #2

Created 10 February 2022 20:03:05 by Junior Thomason

Updated 10 February 2022 20:06:47 by Junior Thomason