

Lead Boost

The Lamb has a hidden Lead Boost feature, this can be useful for adding just a touch of output volume or adding a significant amount of output volume for lead lines or solos (will not affect your gain/breakup).

Double tap the Preset switch to auto engage the Lead Boost, once engaged the Preset LED will begin to flash indicating the Lead Boost is engaged. To exit the Lead Boost, simply press the Preset Switch.

The volume of the Lead Boost is user definable and can be changed/stored in permanent memory via the configuration menu at startup, see ["Using the Pedal"](#) for more info.

Revision #2

Created 1 February 2022 16:10:12 by Junior Thomason

Updated 1 February 2022 16:17:50 by Junior Thomason