

Why is my Lamb not responding to MIDI messages?

Currently there are multiple types of wiring options for cables and connectors. We comply to the MIDI specifications for TRS standards, meaning the tip is active, the ring requires 5 volts and the sleeve is grounded. It is likely that the cable you're using does not meet these standards. Please contact us for recommendations on cables.

Revision #1

Created Thu, Feb 10, 2022 8:30 PM by Junior Thomason

Updated Thu, Feb 10, 2022 8:31 PM by Junior Thomason