

Saving Presets

Saving a preset is simple and quick. Cue up the current preset location you'd like to save a preset to (identified by the color of the Mix LED). Change the active algorithm (if desired) and dial in the settings on the toggle switch and knobs. Once you have a sound that you like, simply hold down the Bypass Switch for 3 seconds. The Bypass LED will flash rapidly indicating the preset has been saved.

***To save a preset the pedal must not be bypassed, you can save a preset in either Live Mode or Preset Mode.

Revision #1

Created 16 August 2023 15:15:54 by Junior Thomason

Updated 16 August 2023 15:16:27 by Junior Thomason