FAQ

Frequently asked questions

- How many presets can I save on the pedal?
- Are there reverb trails when switching between presets?
- Does the Revelation go 100% wet?
- Can I use the Revelation in Mono?
- Why is my Revelation not responding to MIDI messages?
- Why is my Revelation acting funny when I plug it in?

How many presets can I save on the pedal?

The Non-Midi Revelation can save 3 presets onboard. The first three presets can be saved by using the buttons and knobs on the pedal.

The MIDI-Enabled Revelation can save 125 presets. The first three presets can be saved by using the buttons and knobs on the pedal. The remaining 122 presets can be saved using a MIDI controller.

Are there reverb trails when switching between presets?

When switching between modes (Live or Preset) or switching between presets, the pedal automatically enters a "graceful transition" state, the Preset LED will begin to flash letting you know that the Decay knob is gracefully returning to its new setting. This only applies when staying within the same algorithm, if you're switching between algorithm, you will not have reverb trails.

Does the Revelation go 100% wet?

Yes, the mix knob ranges from 0 (100% dry) to 100% wet.

Can I use the Revelation in Mono?

Yes, using the L input and the L output will run the Revelation in mono. Anytime you plug into the R input, it pulls up the stereo algorithms on the pedal.

You can also use the Revelation with mono input and stereo output by plugging into the L input and then using both outputs on the Revelation.

Why is my Revelation not responding to MIDI messages?

Currently there are multiple types of wiring options for cables and connectors. We comply to the MIDI specifications for TRS standards, meaning the tip is active, the ring requires 5 volts and the sleeve is grounded. It is likely that the cable you're using does not meet these standards. Please contact us for recommendations on cables.

Why is my Revelation acting funny when I plug it in?

If your Revelation is making a funny noise or the LEDs are flashing white, it is likely that your power supply isn't providing enough power. The Revelation requires at least 200ma to function properly. Please check your power supply and make sure you're not plugged into a 100ma port. Under powering your pedal for any period of time can damage the unit and will void your warranty.