

# -1 BPM

Used to decrease the MIDI clock by 1 BPM.



The image shows a screenshot of a MIDI controller's software interface. At the top left, there is a pink circular button with a left-pointing arrow. To its right are two dropdown menus: 'Message #' set to 'Message 1' and 'Midi Channel:' set to 'Channel 1'. Below these are two more dropdown menus: 'Press Action:' set to 'Press' and 'Message Type:' set to '-1 BPM'. At the bottom, there are three horizontal sliders labeled 'Number:', 'Value 1:', and 'Value 2:'. Each slider has a pink knob positioned at the left end, with a '0' and a '-' sign to the left and a '+' sign to the right. Below the sliders, the text 'Hold BPM Dial for 3s to Clear Preset' is displayed.

Message #: Message 1 ▾

Midi Channel: Channel 1 ▾

Press Action: Press ▾

Message Type: -1 BPM ▾

Number: 0 - [Slider] +

Value 1: 0 - [Slider] +

Value 2: 0 - [Slider] +

Hold BPM Dial for 3s to Clear Preset

Revision #1

Created Mon, Jun 10, 2024 4:57 PM by Junior Thomason

Updated Wed, Jun 12, 2024 6:39 PM by Junior Thomason