

# CC Messages

Sending CC messages to the Unity6 will control various parameter of the pedal.

- **CC #7 - Increment Bank Number**
  - Value 127 will increase the bank number by a value of 1
- **CC #8 - Decrement Bank Number**
  - Value 127 will decrease the bank number by a value of 1
- **CC #9 - Previous Bank**
  - Value 127 will jump to the previous bank
- **CC #11 - Toggle On/Off Loop 1**
  - Value 0 thru 63 - Loop 1 Off
  - Value 64 thru 127 - Loop 1 On
- **CC #12 - Toggle On/Off Loop 2**
  - Value 0 thru 63 - Loop 2 Off
  - Value 64 thru 127 - Loop 2 On
- **CC #13 - Toggle On/Off Loop 3**
  - Value 0 thru 63 - Loop 3 Off
  - Value 64 thru 127 - Loop 3 On
- **CC #14 - Toggle On/Off Loop 4**
  - Value 0 thru 63 - Loop 4 Off
  - Value 64 thru 127 - Loop 4 On
- **CC #15 - Toggle On/Off Loop 5**
  - Value 0 thru 63 - Loop 5 Off
  - Value 64 thru 127 - Loop 5 On
- **CC #16 - Toggle On/Off Loop 6**
  - Value 0 thru 63 - Loop 6 Off
  - Value 64 thru 127 - Loop 6 On

---

Revision #4

Created Mon, Jun 10, 2024 6:32 PM by Junior Thomason

Updated Tue, Jul 23, 2024 2:00 PM by Junior Thomason