


# Expression to Volume

The Unity6 now has the ability to use a single expression pedal to control/send MIDI expression messages AND it can be used as a standard volume pedal. This can be saved on a per bank basis meaning one bank it can be a volume pedal and then jump to a different bank and use it as an expression pedal to control parameters like Wah, Phaser, Decay Time, Repeats, etc.



Clicking on either checkbox will make the expression pedal as a volume pedal and it will disable the Exp Pedal control for that Bank.



Name: Bank #1



Bank #: 1 -  +



Programming



Bank Info




Scribble Strips



Exp1 to Volume



Exp2 to Volume



Revision #5

Created 14 November 2024 21:05:24 by Junior Thomason

Updated 5 May 2025 16:23:58 by Junior Thomason