


Expression to Volume

*** This Feature is Included in Firmware Version v2.0.0 and Above. ***

The Unity6 now has the ability to use a single expression pedal to control/send MIDI expression messages AND it can be used as a standard volume pedal. This can be saved on a per bank basis meaning one bank it can be a volume pedal and then jump to a different bank and use it as an expression pedal to control parameters like Wah, Phaser, Decay Time, Repeats, etc.




Clicking on either checkbox will make the expression pedal as a volume pedal and it will disable the Exp Pedal control for that Bank.



Name: Bank #1




Bank #: 1 -  +



Programming



Bank Info




Scribble Strips



Exp1 to Volume



Exp2 to Volume



Revision #4

Created Thu, Nov 14, 2024 9:05 PM by Junior Thomason

Updated Thu, Nov 14, 2024 9:36 PM by Junior Thomason