

# Jump to Bank

Used to jump to any bank within the Unity6.

Select the Bank # to jump to that bank.

← Message #: Message 1

Midi Channel: Channel 1

Press Action: Press

Message Type: Jump to Bank

Bank #: 90

Value 1: 0

Value 2: 0

Hold BPM Dial for 3s to Clear Preset

---

Revision #1

Created 10 June 2024 15:39:36 by Junior Thomason

Updated 10 June 2024 16:51:44 by Junior Thomason