

Jump to Bank

Used to jump to any bank within the Unity6.

Select the Bank # to jump to that bank.



← Message #: Message 1 ▼ Midi Channel: Channel 1 ▼

Press Action: Press ▼ Message Type: Jump to Bank ▼

Bank #: 90 - +

Value 1: 0 - +

Value 2: 0 - +

Hold BPM Dial for 3s to Clear Preset

Revision #1

Created Mon, Jun 10, 2024 3:39 PM by Junior Thomason

Updated Mon, Jun 10, 2024 4:51 PM by Junior Thomason