

# Last Used Bank

Used to return to the last used bank within the Unity6.



Message #:  
Message 1 ▾

Midi Channel:  
Channel 1 ▾

Press Action:  
Press ▾

Message Type:  
Last Used Bank ▾

Number: 0 -  +

Value 1: 0 -  +

Value 2: 0 -  +

Hold BPM Dial for 3s to Clear Preset

Revision #1  
Created 10 June 2024 15:42:56 by Junior Thomason  
Updated 10 June 2024 16:51:44 by Junior Thomason