

Last Used Bank

Used to return to the last used bank within the Unity6.



Message #:
Message 1 ▾

Midi Channel:
Channel 1 ▾

Press Action:
Press ▾

Message Type:
Last Used Bank ▾

Number: 0 -  +

Value 1: 0 -  +

Value 2: 0 -  +

Hold BPM Dial for 3s to Clear Preset