

# MIDI Clock BPM

Used to send MIDI clock information.

Select the BPM which ranges from 40 to 240 BPM.



The image shows a digital control interface for MIDI Clock BPM. It features a dark blue background with white and pink text and controls. At the top left, there is a pink circular button with a left-pointing arrow. To its right are two dropdown menus: 'Message #' set to 'Message 1' and 'Midi Channel:' set to 'Channel 1'. Below these are two more dropdown menus: 'Press Action:' set to 'Press' and 'Message Type:' set to 'Midi Clock BPM'. In the center, there is a BPM slider with a pink knob, currently set to 86. Below the slider are two more sliders, 'Value 1' and 'Value 2', both set to 0. At the bottom, there is a text instruction: 'Hold BPM Dial for 3s to Clear Preset'.

Message #: Message 1

Midi Channel: Channel 1

Press Action: Press

Message Type: Midi Clock BPM

BPM: 86 - +

Value 1: 0 - +

Value 2: 0 - +

Hold BPM Dial for 3s to Clear Preset

Revision #1

Created Mon, Jun 10, 2024 4:47 PM by Junior Thomason

Updated Wed, Jun 12, 2024 6:39 PM by Junior Thomason