Note Messages

Sending MIDI Note messages to the Unity6 will activate presets and press actions on the pedal

- **Number #1 - Switch 1**
  - Value 1 - Fires the MIDI messages assigned to the "Press" press action
  - Value 2 - Fires the MIDI messages assigned to the "Release" press action
  - Value 3 - Fires the MIDI messages assigned to the "Long Press" press action
  - Value 4 - Fires the MIDI messages assigned to the "Long Press Release" press action
  - Value 5 - Fires the MIDI messages assigned to the "Double Tap" press action
  - Value 6 - Fires the MIDI messages assigned to the "Double Tap Long Press" press action
  - Value 7 - Fires the MIDI messages assigned to the "Double Tap Long Press Release" press action

- **Number #2 - Switch 2**
  - Value 1 - Fires the MIDI messages assigned to the "Press" press action
  - Value 2 - Fires the MIDI messages assigned to the "Release" press action
  - Value 3 - Fires the MIDI messages assigned to the "Long Press" press action
  - Value 4 - Fires the MIDI messages assigned to the "Long Press Release" press action
  - Value 5 - Fires the MIDI messages assigned to the "Double Tap" press action
  - Value 6 - Fires the MIDI messages assigned to the "Double Tap Long Press" press action
  - Value 7 - Fires the MIDI messages assigned to the "Double Tap Long Press Release" press action

- **Number #3 - Switch 3**
  - Value 1 - Fires the MIDI messages assigned to the "Press" press action
  - Value 2 - Fires the MIDI messages assigned to the "Release" press action
  - Value 3 - Fires the MIDI messages assigned to the "Long Press" press action
  - Value 4 - Fires the MIDI messages assigned to the "Long Press Release" press action
  - Value 5 - Fires the MIDI messages assigned to the "Double Tap" press action
  - Value 6 - Fires the MIDI messages assigned to the "Double Tap Long Press" press action
  - Value 7 - Fires the MIDI messages assigned to the "Double Tap Long Press Release" press action

- **Number #4 - Switch 4**
  - Value 1 - Fires the MIDI messages assigned to the "Press" press action
  - Value 2 - Fires the MIDI messages assigned to the "Release" press action
  - Value 3 - Fires the MIDI messages assigned to the "Long Press" press action
  - Value 4 - Fires the MIDI messages assigned to the "Long Press Release" press action
  - Value 5 - Fires the MIDI messages assigned to the "Double Tap" press action
  - Value 6 - Fires the MIDI messages assigned to the "Double Tap Long Press" press action

- Value 7 - Fires the MIDI messages assigned to the "Double Tap Long Press Release" press action

- **Number #5 - BPM Dial**
  - Value 1 - Fires the MIDI messages assigned to the "Press" press action
  - Value 2 - Fires the MIDI messages assigned to the "Release" press action
  - Value 3 - Fires the MIDI messages assigned to the "Long Press" press action
  - Value 4 - Fires the MIDI messages assigned to the "Long Press Release" press action
  - Value 5 - Fires the MIDI messages assigned to the "Double Tap" press action
  - Value 6 - Fires the MIDI messages assigned to the "Double Tap Long Press" press action
  - Value 7 - Fires the MIDI messages assigned to the "Double Tap Long Press Release" press action

---