

Note Off

Used to send MIDI note off information.

Select Number/MIDI Note and Channel.

← Message #: Message 1 ▼ Midi Channel: Channel 1 ▼

Press Action: Press ▼ Message Type: Note Off ▼

Number: 39 - + D#2

Velocity: 0 - +

Value 2: 0 - +

Hold BPM Dial for 3s to Clear Preset

Revision #2

Created Mon, Jun 10, 2024 4:42 PM by Junior Thomason

Updated Wed, Jun 12, 2024 6:39 PM by Junior Thomason