


# Note On

Used to send MIDI note on information.

Select Number/MIDI Note, Velocity, and Channel.



The screenshot shows a dark-themed interface for configuring a MIDI Note On message. It includes a back arrow icon, dropdown menus for Message # (Message 1), Midi Channel (Channel 1), Press Action (Press), and Message Type (Note On). Below these are three sliders: Number (set to 39, labeled D#2), Velocity (set to 127), and Value 2 (set to 0). Each slider has minus and plus buttons at its ends. At the bottom, a text instruction reads: 'Hold BPM Dial for 3s to Clear Preset'.

Control	Value
Message #	Message 1
Midi Channel	Channel 1
Press Action	Press
Message Type	Note On
Number	39 (D#2)
Velocity	127
Value 2	0

Hold BPM Dial for 3s to Clear Preset

Revision #3

Created Mon, Jun 10, 2024 4:35 PM by Junior Thomason

Updated Wed, Jun 12, 2024 6:39 PM by Junior Thomason