PC Messages

Sending PC messages to the Unity6 will change/jump to the respective bank number.

- PC# 1 - Bank #1
- PC #2 - Bank #2
- PC #3 - Bank #3
- ...
- ...
- ...
- PC #127 - Bank #127

Revision #1
Created 10 June 2024 18:12:33 by Junior Thomason
Updated 12 June 2024 18:39:34 by Junior Thomason