

# PC Messages

Sending PC messages to the Unity6 will change/jump to the respective bank number.

- PC# 1 - Bank #1
- PC #2 - Bank #2
- PC #3 - Bank #3
- ...
- ...
- ...
- PC #127 - Bank #127

---

Revision #1

Created Mon, Jun 10, 2024 6:12 PM by Junior Thomason

Updated Wed, Jun 12, 2024 6:39 PM by Junior Thomason