PC

Generally used to recall presets on your Midi device

Enter the Number and Channel for which to send your message



Revision #4
Created 10 June 2024 15:16:50 by Junior Thomason
Updated 10 June 2024 16:51:44 by Junior Thomason