

Red Remote Off

Used to turn off/deactivate the Red Remote feature found on various JHS pedals

You can control up to 4 separate JHS pedals by plugging each pedal into any of the 4 UniPorts. Before you can control the Red Remote, you must assign the appropriate UniPort to be used for each JHS Pedal. See [here](#) for instruction on programming each UniPort.

Select the UniPort number to control the JHS pedal that is plugged into the corresponding UniPort



Message #: Message 1

Midi Channel: Channel 1

Press Action: Press

Message Type: Red Remote Off

UniPort: 3

Value 1: 0

Value 2: 0

Revision #1

Created Fri, Nov 15, 2024 4:33 PM by Junior Thomason

Updated Fri, Nov 15, 2024 4:56 PM by Junior Thomason