


Red Remote Off

Used to turn off/deactivate the Red Remote feature found on various JHS pedals

You can control up to 4 separate JHS pedals by plugging each pedal into any of the 4 UniPorts. Before you can control the Red Remote, you must assign the appropriate UniPort to be used for each JHS Pedal. See [here](#) for instruction on programming each UniPort.

Select the UniPort number to control the JHS pedal that is plugged into the corresponding UniPort



Revision #1

Created 15 November 2024 16:33:57 by Junior Thomason

Updated 15 November 2024 16:56:38 by Junior Thomason