
Red Remote Off

Used to turn off/deactivate the Red Remote feature found on various JHS pedals

You can control up to 4 separate JHS pedals by plugging each pedal into any of the 4 UniPorts. Before you can control the Red Remote, you must assign the appropriate UniPort to be used for each JHS Pedal. See here for instruction on programming each UniPort.

Select the UniPort number to control the JHS pedal that is plugged into the corresponding UniPort



Revision #1
Created 15 November 2024 16:33:57 by Junior Thomason
Updated 15 November 2024 16:56:38 by Junior Thomason