

# Red Remote On

Used to turn on/activate the Red Remote feature found on various JHS pedals

You can control up to 4 separate JHS pedals by plugging each pedal into any of the 4 UniPorts. Before you can control the Red Remote, you must assign the appropriate UniPort to be used for each JHS Pedal. See [here](#) for instruction on programming each UniPort.

Select the UniPort number to control the JHS pedal that is plugged into the corresponding UniPort

← Message #: Message 1 ▼

Midi Channel: Channel 1 ▼

Press Action: Press ▼

Message Type: Red Remote On ▼

UniPort: 3 - +

Value 1: 0 - +

Value 2: 0 - +

---

Revision #3

Created Fri, Nov 15, 2024 4:17 PM by Junior Thomason

Updated Fri, Nov 15, 2024 4:56 PM by Junior Thomason