


Start MIDI Clock

Used to start the MIDI clock after a Stop MIDI Clock message type has been executed.



The image shows a dark-themed user interface for configuring a MIDI preset. At the top left, there is a circular icon with a left-pointing arrow. The interface is organized into two columns. The left column contains 'Message #:' (set to 'Message 1'), 'Press Action:' (set to 'Press'), and three sliders for 'Number:', 'Value 1:', and 'Value 2:', all of which are currently set to 0. The right column contains 'Midi Channel:' (set to 'Channel 1') and 'Message Type:' (set to 'Start MIDI Clock'). At the bottom, a text instruction reads 'Hold BPM Dial for 3s to Clear Preset'.

Message #:	Message 1	Midi Channel:	Channel 1
Press Action:	Press	Message Type:	Start MIDI Clock
Number:	0		
Value 1:	0		
Value 2:	0		

Hold BPM Dial for 3s to Clear Preset

Revision #1

Created Mon, Jun 10, 2024 5:00 PM by Junior Thomason

Updated Wed, Jun 12, 2024 6:39 PM by Junior Thomason