

Toggle Boost

Used to toggle on/off the post loop clean boost.

Select between 3dB, 5dB, 7dB, 9dB, or 12dB of clean boost.



The screenshot shows a configuration screen for a 'Toggle Boost' function. It features a dark blue background with white and yellow text. At the top left is a yellow circular arrow icon. The settings are organized into two columns. The left column includes 'Message #:' (set to 'Message 1'), 'Press Action:' (set to 'Press'), and 'Boost:' (set to 4). The right column includes 'Midi Channel:' (set to 'Channel 1'), 'Message Type:' (set to 'Toggle Boost'), and a slider for '9 dB'. Below these are two more sliders for 'Value 1' and 'Value 2', both set to 0. At the bottom, a text instruction reads 'Hold BPM Dial for 3s to Clear Preset'.

Parameter	Value
Message #:	Message 1
Midi Channel:	Channel 1
Press Action:	Press
Message Type:	Toggle Boost
Boost:	4
Value 1:	0
Value 2:	0

Hold BPM Dial for 3s to Clear Preset

Revision #2

Created Mon, Jun 10, 2024 3:59 PM by Junior Thomason

Updated Mon, Jun 10, 2024 4:51 PM by Junior Thomason