
Program Change Press-N-Release

Similar to PC Toggle but operates in a momentary fashion

> Enter the PC#'s and Channel for which to send your message.
>
> This feature works in a momentary fashion, when pressing (and holding) the button associated with this Midi type, the PC# above Press will be sent. When releasing the button associated with this Midi type, the PC# above Release will be sent.
>
> This Midi type can be used to temporarily jump to one preset, such as a preset set for large swells, and then quickly return back to your original preset.
>
> * When using this Midi type ***and you expect to hold the button down for longer than a half of a second***. *Both the short press and long press of the same button must be assigned to this Midi type and must also use the same values*, if not, the desired result may not be as expected.



Revision #5
Created 27 July 2020 01:35:31 by Junior Thomason
Updated 30 July 2020 02:07:09 by Junior Thomason